

## 2.54cm (1in ) Toyo Proxes

**Product Code:** 64 2010

**Price:** \$42.85



### Short Description

**TOYO** Tire

[Accessories](#) << >> [TredWear Classicssic](#) <<

Toyo Proxes Kits are officially licensed by Toyo Tire. Our Toyo Proxes letter size is 2.54cm (1in ) and 3.81cm (1.5in ) x 1/16" thick kits, and are created from real white rubber. Our Letters will hold up the force from a high-pressure washer.

### Description

*Taking tires from plain to amazing!*

Single wheel kits

### **How To Order :**

Select the font size.

Enter the number of kits your ordering in the quantity or (QTY) field at the bottom

## **ADHESIVE INCLUDED: With 4 Wheel kits Only**

**Colours: White are stock items,**

Shipping:

Our Normal way of shipping is with Canada Post Expedited Parcel.

You can also choose:

priority post-NextDay delivery or 1 to 2 days depending on your location.

Parcel xpresspost 3 to 5 days.

This is an extra charge. If you do not want the extra service leave unchecked.

Courier Services are used also by customer's request. For that item that just has to be there. Call (902) 650-0152 to schedule for a Courier Service.

## **Install Guide**

### ***Customer's Install Guide***



***Note: Don't install below 18° C ( 64° F )***

We Usually remove the tire before installation. It makes it easier to have gravity working with you. Or you may prefer not to remove your wheel to install your letters. However, to apply your letters always start at the top of the tire, and do half of the tire at a time. This makes it easier to fit the letters to the tire. Rotate the tire by using the jack.

Wash your tires with a strong de-greaser. wipe or let air dry. Now Sand with 80g sandpaper to the area where the letters are going to be placed. Clean the tire several times with acetone till you don't see any black residue on your cloth. ( All tire paint, wax, and dressings has to be removed ). let dry for 2 to 4 min, then clean with the 99% Isopropyl alcohol or you can use 90% rubbing alcohol. Before installing, bath the letters in the alcohol, pat with a clean cloth and let air dry. now you are ready to install. The 20g bottle of adhesive will normally do up to three vehicles, place a thin coat of adhesive on each letter, spread the adhesive around making sure all corners are covered. so when you place the letter on the tire you'll have a small bead of adhesive around the outside edge of the letter. if you don't have a bead of glue around the letter that's fine. You don't want a larger amount of glue around your letter, too much glue can cause the adhesive not to bond properly.



***PDF Download***

## Guide d'installation



**Note: Ne pas installer en dessous de 18° C ( 64° F )**

Nous enlevons normalement la roue avant l'installation. C'est ainsi plus facile de travailler avec la gravité de votre côté. Il est aussi possible de les installer en place, mais l'installation est plus difficile. Dans tous les cas, pour appliquer vos lettres, vous devez toujours débiter au haut de votre pneu, et ainsi coller la moitié d'un pneu à la fois. C'est ainsi plus facile d'agencer les lettres au pneu.

Nettoyez votre pneu à l'aide d'un puissant dégraissant, nettoyez ou laissez sécher. À l'aide d'un papier sabler Grade 80., sablez la région que vous avez préalablement choisie pour apposer vos lettres. Nettoyez le pneu plusieurs fois si nécessaire avec de l'Acétone jusqu'à ce qu'il n'y ait plus aucun résidu noir sur votre serviette. (Armor All et autre brillant à pneu doit être complètement enlevé) Laissez sécher de 2 à 4 minutes, ensuite nettoyez avec de l'alcool 99% Isopropyl ou vous pouvez aussi utiliser de l'alcool 90%. Avant l'installation nettoyez les lettres de chaque côté et laissez sécher.

La bouteille de colle adhésive 20g va normalement faire de 1 à 3 véhicules. Placez seulement une fine couche d'adhésif sur l'endos de chaque lettre. Étendre l'adhésif jusqu'aux extrémités afin de couvrir toute la lettre. Ne pas laisser la colle dépasser la lettre, cela indique que vous avez appliqué trop de colle, ce qui peut créer l'effet contraire.



**PDF Télécharger**